

JaguarBoard

X86-based Single Board Computer

Username: root
Password:111111




Step 1: Prepare below things:

- * One JaguarBoard
- * One USB keyboard (mouse)
- * HDMI displayer
- * Power

Step 2: Startup OS

We have installed Fedora-Server-DVD-x86_64-22 ,if you want to change an OS, please refer to our wiki: <http://jaguarboard.org:8090/display/ED/JaguarBoard+Quick+Start+Guide>



JaguarBoard Specification

Dimension	101.9mm x 64.5mm x 1.6mm
CPU Model	Intel Atom Z3735G
Memory	1GB DDR3L
Storage Capacity	On Board 16GB eMMC
Operating Systems	Linux/Android/Windows
Power On/Off	ATX style
Power Supply	5V/2A
HDMI	1 x HDMI1.4, up to 1080P
Network Interface	1 x 10/100M
USB	3 x USB 2.0
TF Socket	1 x SDIO3.0
Audio	Stereo speaker, Mono mic in, 3.5mm
COM Ports	2
I2C	1
GPIO	4 GPIO Pins

The user manual is available at :<http://jaguarboard.org:8090/dashboard.action>

If you have any question, please do not hesitate to contact our Technical Support for help: support@jaguarboard.org.